



How to change WiFi Name and Password using HiLink App


Click Setting




Click My WiFi



Type desired WiFi name and password and save

 Saving screenshot

 My Wi-Fi

After the Wi-Fi name or password is changed, reconnect to the Wi-Fi network

Wi-Fi name

To Change WiFi Name

Password

To change WiFi Password

Hide SSID [How to connect?](#)

Note: If the SSID is hidden, you must manually enter the SSID of you device to connect to its Wi-Fi network.