


How to Reset my 4G Wingle?



Step: 1 Open the lid (push towards the arrow sign)



Step 2: Press the reset button for few seconds”.

